





(Dish 1000)



DP Plus Twin

DP Dual

(Dish 500 + must carry)



TV 2



This will diplex tv2 out, AND move the tv2 antenna to the tv2 location, to make the remote control work/ better for TV2.



TV 1